## **INSTALLATION INSTRUCTIONS**





#### DUCATI HYPERMOTARD 939 | 2016 F1911

# 1>READ

#### **WARNINGS > INSTALLING**



- We strongly suggest that an experienced technician install this product.
- Read through all instructions before beginning installation.
- This document is intended for use by qualified technicians.
- This is not a replacement for the factory Engine Control Unit (ECU).
- Refer to a factory service manual for more specific stock component identification/location information and removal/assembly procedures.

#### **WARNINGS > USING**



- Use only in race or other closed-course applications and never on public roads.
- Z-Fi products are not certified by the California Air Resource Board (CARB) for use on CA highways.

#### **GETTING HELP**



- Factory support is available in the US at 909-597-8300.
- For fastest support outside of the US, find your local importer at bazzaz.net.


# 2>IDENTIFY

#### **INCLUDED PARTS**

- 1. Z-Fi control unit
- 2. Fuel harness
- 3. Scotchlok (1)
- 4. USB cable
- 5. Swingarm stickers
- 6. Velcro
- 7. Download Bazzaz software from bazzaz.net/index.php/software-overview

#### **FUEL HARNESS**

- 1. Main
- 2. ZAFM
- 3. Ground
- 4. +12v SW Power
- 5. Map Select
- 6. Rear Injector
- 7. Gear
- 8. TPS
- 9. CKPS
- 10. Front Injector



# 3>REMOVE

#### \*\*\*DO NOT DISCONNECT THE FACTORY ECU DURING THE INSTALLATION\*\*\*

- 1. Rider seat.
- 2. Left and right side fairing.
- 3. Fuel tank.

# 4>SECURE


1. The Bazzaz control unit will be on top of the factory ECU beneath the rider seat.



# 5>CONNECT

## 5.1

1. Connect the Bazzaz fuel harness and begin to route the harness towards the air box along the left hand side of the bike as shown in the picture below.



# 5>CONNECT

## 5.2

- Locate the factory rear injector connector which can be found at the rear of the air box.
- 2. Carefully disconnect the factory injector connector and install the Bazzaz rear

#### 5.3


- 1. Locate the factory small white gear position connector which can be found on the right hand side of the bike.
- 2. Disconnect the factory gear position connectors and install the Bazzaz GPS connectors inline.


## 5.4

- 1. Locate the factory TPS lead which can be found beneath the airbox on the right hand side of the bike.
- Carefully make a small cut into the factory sheathing to expose the factory wires.
   Once the wires are exposed separate the factory orange/brown wire. Using the supplied scotchlok crimp onto the factory orange/brown and connect the Bazzaz TPS connector.

## 5.5

- 1. Locate the factory CKPS connectors which can be found rubber mounted to the frame on the right hand side of the bike.
- 2. Disconnect the factory CKPS connectors and install the Bazzaz CKPS connectors inline.










# 5>CONNECT (CONT.) 5.6

- 1. Locate the factory front injector connector which can be found on top of the front cylinder near the radiator.
- 2. Carefully disconnect the factory injector connector and install the Bazzaz injector connectors inline. (To ease in the installation you may loosen the radiator to create more space).



## 5.7

- 1. Locate the white tail light connector in the tail section of the bike.
- 2. Disconnect the factory tail light connector and install the Bazzaz switched power connector inline.



## 5.8

1. Locate the factory negative battery terminal and install the Bazzaz ground lug.



# 6>CHECK



- 1. In order to check that the system is installed correctly, download the Bazzaz Z-Fi Mapper software at bazzaz.net.
- 2. Plug the USB cable into the control unit and computer.
- 3. Locate and open the Z-Fi Mapper software.
- 4. Check that the pre-programmed map matches the model of your bike on the fuel map page within the software. You can switch from map 1 to map 2 by unplugging the map select jumper on the Bazzaz fuel harness. Map 1 will be pre-programmed; depending on your model, there may be a pre-programmed map in the map 2 slot. If map 2 is blank, stock ECU settings are used. Make sure that the jumper is left plugged in or unplugged, depending on which map you choose.
- 5. Start the vehicle and begin to check that the following inputs read correctly on the fuel map page.
- RPM Make sure that the RPM is reading near what the vehicle is idling at.
- GPS The vehicle should read neutral (or whichever gear it is in). For
  motorcycles that use a Gear Position Sensor, the bike does not need
  to be running to do this. For motorcycles that use a speed sensor, the
  wheel must be spinning to read gear properly. This can be checked
  on a dynamometer or by using a rear stand. Use caution when testing
  componentry.
- TPS When throttle is applied, the TPS should read accordingly. Flyby-wire models must be running to check TPS. Normal cable operated throttles can be checked with just the key on, not running.

#### Also use software to:

- View and/or make adjustments to fuel maps
- Activate Z-AFM self mapper (sold separately)
- Save and load new fuel maps
- · Re-calibrate throttle position sensor after throttle modifications
- View diagnostics for troubleshooting
- · Change quickshift settings
- · Make traction control adjustments



If any problem is found, please carefully follow through the installation steps again.



If problem still persists, please contact Bazzaz tech support

- Factory support is available in the US at 909-597-8300.
- For fastest support outside of the US, find your local importer at bazzaz.net

# 7>REINSTALL

After it is determined that everything is correct, reinstall the components removed in step 3.

# 8>USE

#### **MAPS**

The Bazzaz controller is capable of storing two maps. You may switch maps by connecting or disconnecting the map select jumper supplied with the kit.

Or use the optional handlebar-mounted switch to switch maps on the fly (sold separately).





MAP 1

# 9>NEXT LEVEL

#### SELF MAPPER

Build race-level fuel maps for your specific modifications, fuel type, engine, and atmospheric conditions simply while riding. O2 sensor mounts into exhaust and control box easily plugs in to any Bazzaz Z-Fi product.

## **MAP SELECT SWITCH**

Switch maps on the fly with this handlebar-mounted switch.

Weatherproof toggle and easy installation.





79.95



#### THE SMARTEST PERFORMANCE TUNING TECHNOLOGY

