



WARNING!

USE ONLY IN RACE OR OTHER CLOSED COURSE APPLICATIONS AND NEVER ON PUBLIC ROADS

Kawasaki Secondary Air Valve Eliminator Kit Instructions
P/N E400

The purpose of the Secondary Air Valve Eliminator Kit is to obtain the best air fuel ratio and reduce the weight of the motorcycle.

Fits Following Applications:
2018-2019 Ninja 400



Parts List:


Bazzaz Air Valve Eliminator
High Temperature Rubber Caps (3)
Zip Ties (4)

Read through all instructions before beginning installation. This document is intended for use by qualified technicians.

1. Unplug the factory secondary air valve and plug the Bazzaz eliminator in place. This will allow you to remove the secondary solenoid assembly without turning the FI light on.



2. Use supplied high temp caps to cap where hoses were attached to each cylinder head and secure with zip ties or the existing hose clamps.



3. You will also need to cap air box and secure with zip ties or the existing hose clamp.

